0

Tap Dial, as outlined.





Key in the number, as outlined.





When the number has been keyed in, tap the **Call** key to place the call.



Keyboard layout



Using the list of contacts to call

To search for someone, tap here to invoke the virtual keyboard and then key in the name or number. Matches will appear as you type. All three lists will be examined for possible matches.







When an entry has been located and selected the *Call* menu will appear.

Tap **Call** to place the call. There are some options available. These are always context sensitive, which means that meaningless options are not shown. For example **Add to Favorites** is not available for entries already residing in the list of Favorites.

Initiating a video conference (optional feature)

Method A (Multisite):



conference.

Method B (MultiWay/CUCM):



Repeat the procedure to add more participants.



Tap **END** to terminate the conference.

Repeat the procedure to add more participants.



Tap **END** to terminate the conference.

Tap the Camera



Connect your source and make sure it is switched on. Tap Share (a), then scroll horizontally (b) to locate the presentation source, if needed. Once located tap the required source.





Tap the three small dots (---), to acess the menu allowing you to preview or to share the content of the selected source.





Tap **Preview**, if you want to check what you will share before you share it, and then tap Share to actually start sharing the content of your source.





Your content will now be viewable by all connected participants. To stop sharing content tap Stop Sharing, as shown.



A tour of the Touch pad



Tap the touch screen to wake up the system, if needed.



Tap a button to activate its function.



Tap the upper left corner to activate /deactivate the Do not disturb feature, to activate/ deactivate the Standby feature, and to access the Settings.

icon to activate self-view and Time of day is camera settings. indicated in the upper right corner. 12:59 **:::** 31

Tap **Dial** to invoke the dial pad.

Tap Contacts to invoke the list of contacts including Favorites, Directory and

History.

Tap Meetings to invoke a list of upcoming scheduled meetings.

Press and hold the left side of the Volume button to decrease the loudspeaker volume and the right side to increase the volume.

Tap Share to start sharing content and to conduct presentations.



button to mute/unmute microphone.

